


Created in COMSOL Multiphysics 6.1



DC Characteristics of a MESFET

This model compares the current-voltage characteristics of a MESFET using the majority carrier only formulation.

Introduction

MOSFETs and MESFETs (metal-semiconductor field-effect transistor) work very similarly. In a MESFET, the gate forms a rectifying junction that controls the opening of the channel by varying the depletion width of the junction.

In this model we simulate the response of a n-doped GaAs MESFET to different drain and gate voltages. For a n-doped material the electron concentration is expected to be orders of magnitude larger than the hole concentration. Accordingly, it is possible to use the majority carrier option to compute an accurate solution with less degrees of freedom than it would normally be needed using the electrons and holes formulation.

Model Definition

The model compares the effect of the carrier formulation on the solution of a 2D MESFET biased with different gate (0, 1, and 2 V) and drain (from 0 to 10 V) voltages.

The geometry is composed of a block of 4 by 0.5 μm . The Schottky contact (gate) has a length of 1 μm . The source (top left) and drain (top right) have both a length of 0.5 μm . [Figure 1](#) shows the model's geometry.




Figure 1: Geometry of the modeled MESFET.

Results and Discussion

[Figure 2](#) plots the drain current as a function of the drain voltage for both studies (electrons and holes and majority carrier only). The result is identical. Note that the number of degrees of freedom used for the first study (electrons and holes) is 1.5 times larger than the number of degrees of freedom used for the second study (majority carrier only).




Figure 2: Drain current as a function of the drain voltage for the electrons and holes and for the majority carrier only (asterisk).

Application Library path: Semiconductor_Module/Transistors/mesfet

Modeling Instructions

From the **File** menu, choose **New**.

NEW

In the **New** window, click  **Model Wizard**.

MODEL WIZARD

- 1 In the **Model Wizard** window, click  **2D**.
- 2 In the **Select Physics** tree, select **Semiconductor>Semiconductor (semi)**.
- 3 Click **Add**.
- 4 Click  **Done**.

GLOBAL DEFINITIONS

Parameters 1

- 1 In the **Model Builder** window, under **Global Definitions** click **Parameters 1**.
- 2 In the **Settings** window for **Parameters**, locate the **Parameters** section.
- 3 In the table, enter the following settings:

Name	Expression	Value	Description
L	1 [um]	1E-6 m	Gate length
Wd	4 [um]	4E-6 m	Device width
Hd	0.5 [um]	5E-7 m	Device height
Ws	1 [um]	1E-6 m	Source width
Wdd	1 [um]	1E-6 m	Drain width
Vg	0 [V]	0 V	Gate voltage
Vd	0 [V]	0 V	Drain voltage
Vs	0 [V]	0 V	Source voltage
Nd	1e16 [1/cm^3]	1E22 1/m ³	Doping

GEOMETRY 1

- 1 In the **Model Builder** window, under **Component 1 (comp1)** click **Geometry 1**.
- 2 In the **Settings** window for **Geometry**, locate the **Units** section.
- 3 From the **Length unit** list, choose μm .

Rectangle 1 (r1)

- 1 In the **Geometry** toolbar, click  **Rectangle**.
- 2 In the **Settings** window for **Rectangle**, locate the **Size and Shape** section.
- 3 In the **Width** text field, type Wd.
- 4 In the **Height** text field, type Hd.
- 5 Locate the **Position** section. In the **x** text field, type $-Wd/2$.

Add points to define the source, drain and gate contacts.

Point 1 (pt1)

- 1 In the **Geometry** toolbar, click  **Point**.
- 2 In the **Settings** window for **Point**, locate the **Point** section.
- 3 In the **x** text field, type $-Wd/2+Ws/2$ $-L/2$ $L/2$ $Wd/2-Ws/2$.
- 4 In the **y** text field, type Hd Hd Hd Hd.

- 5 Click  **Build All Objects**.

ADD MATERIAL

- 1 In the **Home** toolbar, click  **Add Material** to open the **Add Material** window.
- 2 Go to the **Add Material** window.
- 3 In the tree, select **Semiconductors>GaAs - Gallium Arsenide**.
- 4 Click **Add to Component** in the window toolbar.
- 5 In the **Home** toolbar, click  **Add Material** to close the **Add Material** window.

SEMICONDUCTOR (SEMI)

Metal Contact 1

- 1 In the **Model Builder** window, under **Component 1 (comp1)** right-click **Semiconductor (semi)** and choose **Metal Contact**.
- 2 In the **Settings** window for **Metal Contact**, locate the **Contact Type** section.
- 3 From the **Type** list, choose **Ideal Schottky**.
- 4 Select Boundary 5 only.
- 5 Locate the **Terminal** section. In the V_0 text field, type $-V_g$.

Metal Contact 2

- 1 In the **Physics** toolbar, click  **Boundaries** and choose **Metal Contact**.
- 2 Select Boundary 3 only.
- 3 In the **Settings** window for **Metal Contact**, locate the **Terminal** section.
- 4 In the V_0 text field, type V_s .

Metal Contact 3

- 1 In the **Physics** toolbar, click  **Boundaries** and choose **Metal Contact**.
- 2 Select Boundary 7 only.
- 3 In the **Settings** window for **Metal Contact**, locate the **Terminal** section.
- 4 In the V_0 text field, type V_d .

Analytic Doping Model 1

- 1 In the **Physics** toolbar, click  **Domains** and choose **Analytic Doping Model**.
- 2 Select Domain 1 only.
- 3 In the **Settings** window for **Analytic Doping Model**, locate the **Impurity** section.
- 4 From the **Impurity type** list, choose **Donor doping (n-type)**.

5 In the N_{D0} text field, type Nd.

Trap-Assisted Recombination 1

1 In the **Physics** toolbar, click  **Domains** and choose **Trap-Assisted Recombination**.

2 Select Domain 1 only.

3 In the **Settings** window for **Trap-Assisted Recombination**, locate the **Shockley-Read-Hall Recombination** section.

4 From the τ_n list, choose **User defined**. From the τ_p list, choose **User defined**.

Adjust the mesh slightly.

MESH 1

Size

In the **Model Builder** window, under **Component 1 (comp1)** right-click **Mesh 1** and choose **Edit Physics-Induced Sequence**.

Size 2

1 In the **Settings** window for **Size**, locate the **Element Size** section.

2 From the **Predefined** list, choose **Finer**.

3 Click  **Build All**.

ADD STUDY

1 In the **Home** toolbar, click  **Add Study** to open the **Add Study** window.

2 Go to the **Add Study** window.

3 Find the **Studies** subsection. In the **Select Study** tree, select **General Studies>Stationary**.

4 Click **Add Study** in the window toolbar.

5 In the **Home** toolbar, click  **Add Study** to close the **Add Study** window.

STUDY 1

Step 1: Stationary

Set up an auxiliary continuation sweep for the 'Vd' parameter.

1 In the **Settings** window for **Stationary**, click to expand the **Study Extensions** section.

2 Select the **Auxiliary sweep** check box.

3 Click  **Add**.

4 In the table, enter the following settings:

Parameter name	Parameter value list	Parameter unit
Vg (Gate voltage)		V

5 Click  **Add**.

6 In the table, enter the following settings:

Parameter name	Parameter value list	Parameter unit
Vg (Gate voltage)	0 1 2	V
Vd (Drain voltage)	range(0, 1, 10)	V

7 From the **Sweep type** list, choose **All combinations**.

8 From the **Reuse solution from previous step** list, choose **Auto**.

9 In the **Home** toolbar, click  **Compute**.

RESULTS

ID Plot Group 4

1 In the **Home** toolbar, click  **Add Plot Group** and choose **ID Plot Group**.

2 In the **Settings** window for **ID Plot Group**, locate the **Legend** section.

3 From the **Position** list, choose **Upper left**.

Global 1

1 Right-click **ID Plot Group 4** and choose **Global**.

2 In the **Settings** window for **Global**, click **Replace Expression** in the upper-right corner of the **y-Axis Data** section. From the menu, choose **Component 1 (comp1)>Semiconductor>Terminals>semi.I0_3 - Terminal current - A**.

3 Locate the **y-Axis Data** section. In the table, enter the following settings:

Expression	Unit	Description
semi.I0_3	A	Electrons and holes

4 In the **ID Plot Group 4** toolbar, click  **Plot**.

ADD STUDY

1 In the **Home** toolbar, click  **Add Study** to open the **Add Study** window.

2 Go to the **Add Study** window.

3 Find the **Studies** subsection. In the **Select Study** tree, select **General Studies>Stationary**.

- 4 Click **Add Study** in the window toolbar.
- 5 In the **Home** toolbar, click  **Add Study** to close the **Add Study** window.

STUDY 2

Step 1: Stationary

- 1 In the **Settings** window for **Stationary**, locate the **Study Extensions** section.
- 2 Select the **Auxiliary sweep** check box.
- 3 Click  **Add**.
- 4 In the table, enter the following settings:

Parameter name	Parameter value list	Parameter unit
Vg (Gate voltage)		V

- 5 Click  **Add**.
- 6 In the table, enter the following settings:

Parameter name	Parameter value list	Parameter unit
Vg (Gate voltage)	0 1 2	V
Vd (Drain voltage)	range (0, 1, 10)	V

- 7 From the **Sweep type** list, choose **All combinations**.
- 8 From the **Reuse solution from previous step** list, choose **Auto**.

SEMICONDUCTOR (SEMI)

- 1 In the **Model Builder** window, under **Component 1 (comp1)** click **Semiconductor (semi)**.
- 2 In the **Settings** window for **Semiconductor**, locate the **Model Properties** section.
- 3 From the **Solution** list, choose **Majority carriers only**.

STUDY 2

In the **Home** toolbar, click  **Compute**.

RESULTS

Global 2

- 1 In the **Model Builder** window, under **Results>ID Plot Group 4** right-click **Global 1** and choose **Duplicate**.
- 2 In the **Settings** window for **Global**, locate the **Data** section.

3 From the **Dataset** list, choose **Study 2/Solution 2 (sol2)**.

4 Locate the **y-Axis Data** section. In the table, enter the following settings:

Expression	Unit	Description
semi.I0_3	A	Majority carriers only

5 Click to expand the **Coloring and Style** section. Find the **Line markers** subsection. From the **Marker** list, choose **Asterisk**.

6 From the **Positioning** list, choose **Interpolated**.

ID Plot Group 4

1 In the **Model Builder** window, click **ID Plot Group 4**.

2 In the **Settings** window for **ID Plot Group**, locate the **Plot Settings** section.

3 Select the **x-axis label** check box. In the associated text field, type **Drain voltage (Vd)**.

4 Select the **y-axis label** check box. In the associated text field, type **Terminal current (A)**.

5 In the **ID Plot Group 4** toolbar, click  **Plot**.

